


Streetlight Point-of-Disconnect Diagram




Customer is responsible for:

- Providing and installing a junction box or pedestal, conduit, fusing and customer-owned wire. The junction box or pedestal must be strong enough for incidental traffic areas
- Coordinating with Rocky Mountain Power on junction box or pedestal location and all digging within the vicinity of Rocky Mountain Power facilities
- Ensuring that construction of new or remodeled installations conform to applicable provisions of the NEC State Rules, as well as city and county codes

Rocky Mountain Power is responsible for:

- Making the connection within Rocky Mountain Power facilities (transformer or secondary box)



STANDARD DETAIL

E-3

STREETLIGHT POINT-OF-DISCONNECT DIAGRAM

NO.	AUTHORIZED BY	REVISIONS	DATE